RYNO® DINING CHAIR 2.0 \rightarrow FLOOR FIXING



These instructions apply only when fixing to a concrete floor with no obstructions (e.g. under floor heating, cables, plumbing, etc.). When fixing to any other surface, or with obstructions, please contact your Pineapple representative for further advice

REQUIRED ITEMS

- → X2 Floor fixing templates
- → X2 Floor brackets
- → X4 Long countersunk head security
- → screws
- \rightarrow X1 Extra long drill bit
- → X1 Counter sink drill bit
- → X4 Concrete hardware fixings
- → X1 Masonry drill bit
- → Handheld power drill
- → X1T25 Security bit



RYNO® DINING CHAIR 2.0 \longrightarrow FLOOR FIXING

		re the template to the ground to templates meet edge to dle.	V JERON	R R V IFRONTIV	
O VIRONIIV	VIFRONTIV	Using a centre punch mark ou fixing locations.	ut the 4 floor	02	
03	Using an appropr suitable for the co	iate masonry drill, create a hole oncrete fixings.	V JERON	CARTILL V IRONTIV	
C C C C C C C C C C C C C C C C C C C	VIFRONTIV	Place the two floor fixing brace drilled holes and secure to the appropriate hardware.		04	

RYNO® DINING CHAIR 2.0 \longrightarrow FLOOR FIXING

05	Place the chair sits completely	over the brackets ensuring it on the ground.	The state of the s		
	·	Using the template, mark two po chair 30mm from the ground an guidelines. Also mark the floor w using the guidelines. Remove the chair and template.	d in line with the vith two lines -	06	
Place the chair back over the brackets. Using the extra-long drill bit slowly drill through the product at the two previously marked points. Make sure it goes through both walls of the floor bracket and remains parallel to the ground. The drill will ideally need lubrication and be at a very low speed.					
	TVITO	Use the counter sink drill bit to counter sink on the surface of		08	

RYNO® DINING CHAIR 2.0 \longrightarrow FLOOR FIXING

09	Drive the Long Security Screws through the previously created holes ensuring the head of the screw ends up flush to the product.	

DISCLAIMER

 → Ensure the proper and adequate hardware is used to secure furniture → Ensure fixings are appropriate for the anchoring material → Use fixings of an appropriate strength and consider using security fixings in challenging environments → Consider using high strength thread-locker on fixings in challenging environments → Ensure all gaps are sealed with the appropriate anti-pick mastic after product installation if necessary → Please read all instructions carefully to ensure proper installation. Failure to read and follow instructions may result inadequate product installation and void of warranty → Pineapple shall not be held liable for any consequences caused by the improper installation of products to the installer or the end user

